Introducing the LG VX3200 pay as you go phone.

Features

- ·Tri-Mode
- ·1XRTT capable
- •Enhanced Messaging Service (EMS) to send and receive text messages with graphics and sound
- •E911 Emergency Location capable
- ·Large 65K STN Main color display (128 x 128)
- ·Two-way TXT Messaging
- ·99 speed dials
- ·Voice Activated Dialing
- Speakerphone
- ·CMX MIDI for polyphonic ringer and sound capability
- ·Large Phone Book: 300 contacts (each stores 5 numbers and 3 email addresses)
- ·36 ringtones plus vibrating alert
- •Personalize Theme Colors (Blue, Green, Violet, Orange) and Font Colors (Black, Blue, Red, Green, Pink)
- TTY/TDD compatible
- ·Bilingual (English and Spanish) capabilities
- ·PC connector type: USB
- ·1-Year limited warranty
- ·Handset insurance coverage: No

Specifications

- •Dimensions: 3.35" x 1.81" x .92"
- ·Weight: 3.53 ounces
- •Standard Lithium Ion (1000 mAh)

Battery:

Mode Usage Standby
Digital Up to 200 min or Up to 180 hr

Battery Charge Time -Standard Battery Pack: Up to 3 Hours







Yes, you can:

with EMS Send & Receive TXT Messages with Graphics & Sound

Store downloadable
Ring Tones,
Graphics &
Wallpaper
purchased through
Vtext.com

Polyphonic Ringers & Sound Capability





Go to www.vtext.com

to learn more about purchasing Ring Tones, Wallpaper & Graphics

*Device does not support Web Browsing & Get It Now®

DYMAX Codes

Device	FRU	Mock-Up
L <i>G-</i> VX3200PP	FRULGVX3200	LG-VX3200DP

Vision ID
3414



Each VX3200 is packaged with:

- •Standard Lithium-Ion Battery (1000 mAh)
- AC Travel Charger
- ·User Guide
- ·Quick Reference Guide
- ·Welcome CD

LG VX3200 pay as you go phone Optional Accessories



VPC - Vehicle Power Charger

LGVPC-1

\$29.99



A/C Travel Charger - In Box

LGTVL-1

\$29.99



Standard Slim Lith Ion Battery (1000 mAh - In Box

3200BATSLG

\$39.99



Extended Lith Ion Battery with battery door (1700 mAh) 3200BATXTLG

\$59.99



Lambskin Leather Case with Swivel

LGCA53200

\$19.99



Limited Supply Only



Combo VPC and Lambskin Leather Case

LGCOM3200

\$39.99



Pre-Packaged Combo Plantronics MX150 Headset, VPC and Leather Case PROM3200COM

\$49.98



Hands-Free VPC

LGVXPHF-1

\$69.99



Holster - Not included In Box

3200HOLLG

\$14.99



Replacement Stub **Antenna**

3200ANTLG

\$9.99

Celebrite Cables

Celebrite cables are used to transfer phonebooks from 1 manufacturer's phone to another manufacturer's phone.

Order cable CEL-68/2LG to support the launch of the VX3200

Support Tools

Merchandising

Please use existing LG VX3200 call out cards to merchandise the floor. Check with your Area Merchandising Contacts if you need additional cards. Link to view Call Out Card is now available on the equipment guide database.

Placement

For placement of the VX3200 pay as you go in the VZW Communications Stores, please refer to the Handset Placement for All Slat walls document found on the Verizon Wireless Intranet Retail Information Site. Just click on the below to view:

http://mkt.vzwcorp.com/marketing/merchandise/index..com

Product Literature

Product use existing LG VX3200 buck slips. To obtain additional literature, please follow Area Procedures. To view an adobe Acrobat file of the VX3200 Buckslip, click on the link below:

http://webfiles.vzwcorp.com/departments/marketing/wep/merchandising/buckslips/lgic/vx3200.pdf

Product Training

Should you require any product training or support, please contact the LG Corporation Account Manager for your Area.

NE Area

Teresa Cangialosi	(201) 988-3325
Ken Bagwell	(919) 779-1504

North Central

Chris Diggory (773) 882-8835

MW Area

Jim Grothjan (513) 245-2027

South Area

Michael Rickert (772) 784-8190 Frank *G*raham (713) 357-2070

West Area

Bill Vlahandreas (707) 537-7888 Jim Lake (858) 735-5341

Helpful Hints

Manually Programming the VX3200

- 1. Press "menu" + 0 and press "000000"
- 2. Press "1" key for Service Programming
- 3. Press "ok" (Read only)
- 4. Input the "Phone number (MDN)" and press "ok"
- 5. Input the "Phone number (MIN)" and press "ok"
- 6. Input the "NAM1 Home SID" and press "ok"
- 7. Input the "NAM1 Name" and press "ok"
- 8. Confirmation "Basic NAM1 is completed" when programmed successfully
- Press Left Soft Key for "Exit". Powering Down will proceed

How to Send a Text Message

- 1. Press the down arrow on the navigation key
- 2. Press 3 for "Messages"
- 3. Press 2. "New Message"
- 4. Enter an SMS phone number or select name from Contact List
- 5. Enter a message up to 160 characters
- 6. Select Options (Right Soft Key) for "Insert Quick-Text", "Insert Object", "Format Text", "Save Quick-Text", or "Insert Signature".
- 7. Press "Ok" and then "Send" to send the message

OTA Instructions

- 1. Perform the usual billing system activation procedure
- 2. Power up the phone and enter the Star Code, *228 + [send], on the handset
- 3. The following audio message will be heard:

"Welcome to Verizon Wireless' Over the Air programming. This call is airtime free. Press '1' to program your phone. Press '2' to update your roaming capabilities."

Note: Programming will take up to 2 minutes. Should the programming exceed 45 seconds, the following audio message will be repeated at 25-second internals: "Please continue to hold. Your phone is being programmed."

You will hear an audio message once the phone has been successfully programmed

How to View the Software Version:

- 1. Press Left Soft Key to select "Menu"
- 2. Press 6, "Settings"
- 3. Press 9, "Phone Info"
- 4. Press 2, "S/W Version""

Features/Advantages/Operation of the VX3200 pay as you go phone

Features	Advantage	Operation
Two way EMS TXT Messaging	Send, Receive & respond to TXT Messages with pictures & Tones to other EMS capable Handsets	Press down on the bottom of the center Navigation Key Press 2, New Message Enter an SMS phone number or select name from Contact List. Enter a message up to 160 characters. Select Options (Right Soft Key) for "Insert Quick-Text", "Insert Object", "Format Text", "Save Quick-Text", or "Insert Signature". Press "Ok" and then "Send" to send the message
My Media Folder	Allows you to store and access pictures, sounds, and animations	Press Left Soft Key then select the Media menu (4). From here you can access My Pictures (3), My Melodies (5), or My animations (7) for numerous customization options.
Two-Way Speaker Phone	Convenient access to turn the speaker phone function on and off	While in standby mode, press the Up Navigation Key with the speaker phone icon, "Speakerphone On" will appear on the screen. To deactivate, press the key again and "Speaker Off" will appear on the screen.
Voice Memo	Quickly verbalize a note for later playback	Under "Voice Memo-Operations", should be rephrase as "From the Tools (5) menu, select Voice Memo (3). Press Left Soft Key for New. Please start recording after the tone and press Left Soft Key for Done. Voice Memo saved.
Change Theme Color	Allows user to personalize the phones display appearance	Press Left Soft Key then Settings (6), select Display (2). Select Theme Colors (6). Use the Navigation Key to select the desired option (Default, Green, Violet or Orange) and press OK.